





WIRING SCHEMATIC

For Automatic Transmissions:
Cut the yellow loop before plugging in the module.



- 3. YELLOW/WHITE (-) PARKING LIGHTS
- 2. BLUE/WHITE ... (-) AUX 1 output
- 1. GRAY/LIGHT BLUE ... (-) AUX 2 output



- 30 A Fuse
- YELLOW IGNITION
- RED 12V (Battery)
- ORANGE... ACCESSORIES (Heater Blower Motor)
- PURPLE..... STARTER
- GREEN 5th RELAY
- 30 A Fuse
- RED +12V (Battery)

- 1- BLACK GROUND (-)
- 2- PURPLE..... TACH (AC)
- 3- GREY HOOD SWITCH (-)
- 4- ORANGE BRAKE SWITCH (+)
- 5- YELLOW PARKING LIGHTS (+)
- 15 A Fuse

- 12- YELLOW (+) Glow plug input
- 11- GREY (-) NEG. Door input
- 10- WHITE (-) GROUND when running
- 9- PURPLE (-) EXT. TRIGGER input
- 8- ORANGE (-) Parking Brakes input
- 7- WHITE/ORANGE (-) Starter kill output
- 6- BLUE/WHITE (+) POS. Door input
- 5- WHITE/GREEN (-) DISARM
- 4- WHITE/BROWN (-) REARM
- 3- GREEN (-) UNLOCK
- 2- BROWN (-) LOCK
- 1- BLUE (-) TRUNK